

### READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Do to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use and

## Solid Sub Frame Mounts

**993**

Check to make sure that you have all parts listed prior to installation. If anything is missing contact us immediately. 802.893.7366

Parts List: Solid Bushings & Tilt Kit  
 (12) Bushings  
 (2) M12x1.5x90 Bolt V.A.G: N-908-235-01  
 (2) M12x1.5x110 Bolt V.A.G: N-907-996-01

Step 1 - Remove factory rubber mounts

Step 2 - Install solid mounts and tilt blocks as shown below.

Step 3 - Torque bolts to 90 ft-lbs.

Solid Bushings  
 (8) Bushings  
 (4) M12x1.5x90 Bolt V.A.G: N-908-235-01

