

Installation Instructions

986, 987, 996, 997 CRANKSHAFT PULLEY

We recommend professional installation.

1. Remove the serpentine drive belt.
2. Remove the original crankshaft pulley using the Porsche crankshaft pulley tool (not provided). The pulley tool can be picked up from any local Porsche dealer.
3. You will need to modify the original protrusion in order for the under drive pulley to fit. This takes patience. You can use a dremel, hacksaw or any tool you deem perfect for trimming down the protrusion. **THIS IS NECESSARY FOR CLEARANCE ON THE NEW PULLEY!** Make sure you clean the area of any debris after cutting before re-assembling.
4. Install the new under drive pulley. Make sure to use the new bolt that is provided with the kit, do not re-use the old bolt (discard it).
5. The new bolt has a two - step torque process:
Step1: torque to 50Nm.
Step 2: Turn an additional 90 degrees.
6. Install the new serpentine belt provided. This belt is specific length for vehicles with or without AC (depending on what your application is), your original belt will not work.
7. Crank the vehicle and ensure everything is working correctly.